

## POWER WINDOWS

### INDIX

#### FRONT POWER WINDOWS

Wiring diagram A . . . . .	23-2
Wiring diagram B . . . . .	23-3
Wiring diagram B . . . . .	23-4
General Description . . . . .	23-4/1
Functional Description . . . . .	23-4/1
Components and Connectors . . . . .	23-5
Location of Components . . . . .	23-9

#### REAR POWER WINDOWS

Schema elettrico . . . . .	23-10
General Description . . . . .	23-11
Functional Description . . . . .	23-11
Components and Connectors . . . . .	23-12
Location of Components . . . . .	23-14

FAULT-FINDING TABLE . . . . .	23-15
-------------------------------	-------

CHECK POWER WINDOW CONTROL UNIT . . . . .	23-16
---	-------







## General Description

### For versions with fusebox "A":

The movement of the **left front** electric window (driver's side) is **automatic**, controlled by a control unit which operates it according to the following logic:

- keeping the pushbutton pressed (over 300 ms) the window opens or closes normally until the pushbutton is released;
- a short pulse (below appr. 300 ms. ) operates the motor which automatically continues and only stops at the end of the stroke (window completely open or closed);
- an even shorter pulse (less than appr. 50 ms.) is considered by the control unit as an accidental shock and no action will result.

This operating logic takes place through the "key-operated" supply.

### For versions with fusebox "B":

The movement of the **left front** window is **manual**: when the button is pressed in one direction or the other the window moves upwards or downwards: this only takes place through the "key-operated" supply.

The electrical mechanism that operates the **right front** window is - in both cases - of the conventional type: when the button is pressed the window rises or drops; it is fitted with two control switches: one on the right-hand door and one on the left-hand door; operation is only possible with the ignition key engaged.

## Functional description

### For versions with fusebox "A" or "C":

The power window control unit **N38** is supplied at pin 2 of connector B by battery voltage through fuse **F22** of fusebox **G1**.

The key-operated enable signal reaches pin 1 of connector A via fuse **F17** (box "A") or fuse **F15** (box "C") still of **G1**.

The control signals for the upward and downward stroke respectively reach pins 4 and 3 of connector A from the left-hand window control switch **B53**.

In fact, this double switch sends an earth to the control

unit from the part in which the contact has been closed.

The operating signals (up or down) leave pins 3 and 4 of connector B of **N38** for left-hand window motor **P15**: 12 V and earth are inverted to change the direction of rotation

Pin 1 of connector B of **N38** is connected to earth.

Conversely, the operation of the right-hand motor is controlled directly by one of the two switches **B21** (**B21a** located on the right-hand door, **B21b** on the left) which are connected in series.

The "key-operated" supply passes through relay **I12**, supplied by direct voltage through the line of fuse **G310**. The relay is energised with the key-operated supply, via fuse **F17** (box "A") or fuse **F15** (box "C") still of **G1**: the righthand window motor **P14** is operated by one of the two switches **B21** in one direction or the other depending on the origin of the 12V or earth signal.

### For versions with fusebox "B":

The power window control unit **N38** comprises a "bridge" on connector B which "relays" the supply and earth to the control switch of the left-hand window **B22**. This supply leads through wander fuse **G311** and relay **I12**.

The "key-operated" consensus is received through fuse **F17** of **G1**.












The double switch **B22** sends the operating signals (up or down) for the left-hand window motor **P15**: 12 V and earth are inverted to change the direction of rotation.

Operation of the right-hand window is controlled directly by one of the two switches **B21** (**B21a** located on the right-hand door, **B21b** on the left) which are connected in series

The "key-operated" supply leads through relay **I12**, energized through the line of fuse **F17** of **G1**, and wander fuse **G310**. The motor for the right-hand window **P14** is operated by one of the two switches **B21** in one direction or in the other depending on the origin of the 2V and earth signals.



### Components and Connectors

RH front power window control switch (on RH door) (*)	<b>B21a</b>	RH front power window control switch (on LH door) (*)	<b>B21b</b>
			
RH front power window control switch (on RH door) (•)	<b>B21a</b>	RH front power window control switch (on LH door) (•)	<b>B21b</b>
			
Front power window switch with automatic device (*)	<b>B53</b>	Front power window switch with automatic device (•)	<b>B53</b>
			
Fusebox	<b>G1</b>	Fusebox	<b>G1</b> <b>A</b>
			


(\*) up to chassis no. \_\_\_  
PA493000000008

(•) from chassis no. \_\_\_

### Components and Connectors (cont.d)


Fusebox

G1 G




Fusebox

G1 H




Fusebox

G1 Q




RH front door wiring connector

G21







### Components and Connectors (cont.d)



### Components and Connectors (cont.d)




### Location of Components





Wiring diagram





## General Description

The electric mechanism that operates the rear windows is of the conventional type (button pressed - in one direction or the other - the window closes or opens): the control switch is located on the centre console and may also be operated from the front seats.


For safety reasons a special consensus switch, also on the centre console, makes it possible to cut off the supply to the switches.

Operation of the rear power windows is only possible with the ignition switch engaged.

## Functional Description

The rear power window relay I13 supplies and controls the entire system.

The relay coil is energised by a "key-operated" signal, leading from the ignition switch supply relay I35 and from fuse F4 of fusebox G1 (box "A") or from fuse F3 of box G1 (box "C");

this supply crosses the safety switch for consensus for the rear power windows B25: if pressed, this switch de-energises the coil of I13, completely cutting off the supply to the circuit, and contemporaneously turning on a led which lights up the ideogram .

Once the coil of relay I13 is energised, switches B23 and B24 are supplied with battery voltage which leads through the rear power window fuse F21 of fusebox G1 (box "A") or through fuse F23 of G1 (box "C").

The double switches supply the motors P16 and P17, sending a supply and an earth, inverting the signals depending on the contact that has been closed, thereby establishing the direction of rotation of the motor.

### Components and Connectors



RH rear power window control switch	(B23)	LH rear power window control switch	(B24)
Rear power window consensus switch	(B25)	Fusebox	(G1) (E)
Fusebox	(G1) (H)	Fusebox	(G1) (G)
Fusebox	(G1) (L)	Fusebox	(G1) (N)




## Components and Connectors (cont.d)

<p><b>RH rear door wiring connector</b></p> <p style="text-align: right;"><b>G25</b></p>	<p><b>LH rear door wiring connector</b></p> <p style="text-align: right;"><b>G27</b></p>
<p><b>Rear power window wiring connector</b></p> <p style="text-align: right;"><b>G29</b></p>	
<p><b>LH rear earth</b></p> <p style="text-align: right;"><b>G63b</b></p>	<p><b>Rear services connector</b></p> <p style="text-align: right;"><b>G73 [B]</b></p>
<p><b>Earth under LH dashboard</b></p> <p style="text-align: right;"><b>G148b</b></p>	<p><b>Rear power window relay</b></p> <p style="text-align: right;"><b>I13</b></p>

Components and Connectors (cont.d)

RH rear power window motor	P16	LH rear power window motor	P17
			

### Location of Components



(•) grey base



### FAULT-FINDING TABLE

Fault	Component to be checked											
	G311 (B)	G310	F17	F22 (A)	P14	P15	N38 (A)	B21a	B21b	I12	B53 (A)	B22 (B)
LH front power window, in all circumstances	•		•	•		•	•			•	•	•
LH front power window, automatic operation				•			•					
RH front power window		•	•		•			•		•		

(cont.d)


(A) Versions with fusebox "A"

(B) Versions with fusebox "B"

Fault	Component to be checked							
	F21	F4	P17	P16	B24	B23	I13	B25
Both rear power windows	•	•					•	•
LH rear power window			•		•			
RH rear power window				•		•		


## CHECKING COMPONENTS

Power window control unit (N38)



Check device:  
test A (only for fusebox "A")

Power window switches (B21a) (B21b) (B22) (B23) (B24)



### SPECIFICATIONS

Check operation:  
**at rest:** continuity between pin 3 and 1 and between pin 2 and 5, a.c. between the other pins  
 operating pushbutton for **closing:** continuity between pin 4 and 1; a.c. between the other pins  
 operating pushbutton for **opening:** continuity between pin 4 and 2, a.c. between the other pins

CHECK POWER WINDOW CONTROL UNIT (N38) (version for fusebox "A")	TEST A
---	--------

Work with the component fitted on its connector, from the cable inlet side

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
A1	CHECK VOLTAGE	OK ▶	Carry out step A2
	– Check for 12V between pin 2 and 1 of connector B of N38	<del>OK</del> ▶	Check fuse F22 of fusebox G1. Restore the wiring between N38 B and G1 and between N38 B and earth G148b
A2	CHECK VOLTAGE	OK ▶	Carry out step A3
	– With the key at MARCIA, check for 12V between pin 1 of connector B and pin 1 of connector A of N38	<del>OK</del> ▶	Check fuse F17 of G1. Restore the wiring between N38 A and G1
A3	CHECK MANUAL OPERATION	OK ▶	Carry out step A5
	– Operating the driver's side front power window switch B53, check for 12V between pin 3 and 4 of connector B of N38; this voltage ceases when operation of the button stops	<del>OK</del> ▶	Carry out step A4
A4	CHECK MANUAL OPERATION	OK ▶	Change device N38
	– Operating switch B53, check for a voltage of 12V between pins 3 and 4 of connector A of N38	<del>OK</del> ▶	Restore the wiring between N38 A and switch B53, or change the latter
A5	CHECK AUTOMATIC OPERATION	OK ▶	DEVICE N38 IS WORKING PROPERLY. Check the connections with the other components
	– With the key at MARCIA, operating switch B53 check for: <ul style="list-style-type: none"> <li>• 12V d.c. between pins 3 and 4 of connector B if the button is pressed for less than 300 ms</li> <li>• no voltage if the button is pressed for less than 50 ms</li> <li>• 12V d.c. between pins 3 and 4 of connector B keeping the button pressed</li> </ul>	<del>OK</del> ▶	Change device N38

