

UPDATE CHART

146

146

VOLUME I

REPAIR

INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
2 (9/1994)	145-146	-	Frontespice	
2 (9/1994)	145-146	Introd.	1	
11 (1/1999)	145-146	00	Index	
11 (1/1999)	145	00	1 to 2	
6 (10/1996)	145	00	3	
11 (1/1999)	145	00	4 to 6	
10 (1/1998)	145	00	6/1	
11 (1/1999)	145	00	6/2	
2 (9/1994)	145	00	7 to 10	
4 (5/1995)	145	00	11	
2 (9/1994)	145	00	12 to 16	
11 (1/1999)	145	00	17	
7 (12/1996)	145	00	18 to 19	
2 (9/1994)	145	00	20 to 21	
7 (12/1996)	145	00	22	
11 (1/1999)	145	00	22/1	
4 (5/1995)	145	00		22/2 to 22/5
11 (1/1999)	145	00	22/6 to 22/7	
6 (10/1996)	145	00		22/8 to 22/10
11 (1/1999)	145	00	22/11 to 22/13	
10 (1/1998)	145	00		22/14 to 22/15
11 (1/1999)	145	00	22/16	
10 (1/1998)	145	00	23 to 25	
11 (1/1999)	145	00	26 to 28	
11 (1/1999)	145	00		28/1 to 28/2
11 (1/1999)	145	00	29	
10 (1/1998)	145	00	30	
7 (12/1996)	145	00	30/1	
11 (1/1999)	145	00	30/2	
11 (1/1999)	145	00	31	
10 (1/1998)	145	00	32	
11 (1/1999)	145	00	32/1 to 32/2	
2 (9/1994)	145	00	33 to 35	
10 (1/1998)	145	00	36 to 52	
11 (1/1999)	145	00		52/1 to 52/2
10 (1/1998)	145	00	53 to 57	
10 (1/1998)	145	00	57/1	
11 (1/1999)	145	00	57/2	
10 (1/1998)	145	00	57/3 to 57/4	
10 (1/1998)	145	00		57/5 to 57/8
11 (1/1999)	145	00		57/9 to 57/10
10 (1/1998)	145	00	58	
2 (9/1994)	145	00	59	

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
6 (10/1996)	145	00		59/1 to 59.2
10 (1/1998)	145	00		59/3 to 59.5
11 (1/1999)	145	00		59/6 to 59.8
2 (9/1994)	145	00	60 to 70	
10 (1/1998)	145	00	71	
2 (9/1994)	145	00	72 to 74	
7 (12/1996)	145	00		74/1 to 74.6
2 (9/1994)	145	00	75 to 79	
4 (5/1995)	145	00	80	
4 (5/1995)	145	00		80/1 to 80.2
6 (10/1996)	145	00	81 to 82	
4 (5/1995)	145	00	83 to 86	
6 (10/1996)	145	00		86/1 to 86.2
11 (1/1999)	145	00		86/3 to 86.10
7 (12/1996)	145	00	87	
11 (1/1999)	145	00	88 to 90	
11 (1/1999)	145	00		90/1 to 90.2
11 (1/1999)	145	00	91a98	
7 (12/1996)	146	00	99	
11 (1/1999)	145	00		100
5 (9/1995)	145	10	Index I-II	
7 (12/1996)	145	10	Index III-IV-V	
11 (1/1999)	145	10	Index VI	
10 (1/1998)	145	10		VII
11 (1/1999)	145	10		VIII
2 (9/1994)	145	10		48/1 to 48.20
4 (5/1995)	145	10	56	
4 (5/1995)	145	10		56/1 to 56.2
4 (5/1995)	145	10	57	
10 (1/1998)	145	10	103	
4 (5/1995)	145	10	115 to 116	
7 (12/1996)	145	10	119	
4 (5/1995)	145	10	124	
4 (5/1995)	145	10	165 to 174	
5 (9/1995)	145	10		174/1 to 174/8
4 (5/1995)	145	10	175	
5 (9/1995)	145	10		175/1 to 175/2
4 (5/1995)	145	10	176 to 194	
7 (12/1996)	145	10	195	
4 (5/1995)	145	10	196	
7 (12/1996)	145	10		196/1 to 196/2
4 (5/1995)	145	10	197 to 202	
7 (12/1996)	145	10		202/1 to 202.6

(continues)

1-1999

UPDATE CHART

146

146

VOLUME I

REPAIR

INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
4 (5/1995)	145	10	203 to 213	
7 (12/1996)	145	10	214 to 215	
4 (5/1995)	145	10	216 to 219	
7 (12/1996)	145	10	220 to 221	
4 (5/1995)	145	10	222	
7 (12/1996)	145	10	223 to 225	
7 (12/1996)	145	10		225/1 a 225/2
7 (12/1996)	145	10	226	
4 (5/1995)	145	10	227 to 234	
7 (12/1996)	145	10	235	
7 (12/1996)	145	10		236 to 260
11 (1/1999)	145	10		260/1 to 260/2 261
9 (12/1997)	145	10		
10 (1/1998)	145	10	262	
11 (1/1999)	145	10	263	
10 (1/1998)	145	10	264	
9 (12/1997)	145	10	265	
10 (1/1998)	145	10	266	
9 (12/1997)	145	10	267	
10 (1/1998)	145	10	268 to 272	
10 (1/1998)	145	10		273 to 274 274/1 to 274/2
11 (1/1999)	145	10		275 to 285
10 (1/1998)	145	10	286 to 309	
11 (1/1999)	145	10		310 to 360
7 (12/1996)	145	18	Index	
4 (5/1995)	145	18		14 to 17
7 (12/1996)	145	18		18
11 (1/1999)	145	21	Index	
3 (1/1995)	145	21	6	
7 (12/1996)	145	21	14	
4 (5/1995)	145	21		15 to 20
7 (12/1996)	145	21	21	
7 (12/1996)	145			22 to 31
11 (1/1999)	145	21		32 to 45
7 (12/1996)	145	27	Index	
2 (9/1994)	145	27	2	
4 (5/1995)	145	27	6	
4 (5/1995)	145	27		10 to 11
7 (12/1996)	145	27		12 to 16
11 (1/1999)	145	33	Index	
4 (5/1995)	145	33	4 to 7	
10 (1/1998)	145	33	7/1	

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
4 (5/1995)	145	33		7/2
7 (12/1996)	145	33	8 to 9	
7 (12/1996)	145	33		9/1 to 9/2
7 (12/1996)	145	33	10	
3 (1/1995)	145	33	15	
7 (12/1996)	145	33	17	
4 (5/1995)	145	33	26	
4 (5/1995)	145	33		27 to 28
7 (12/1996)	145	33		29 to 38
11 (1/1999)	145	33	39	
7 (12/1996)	145	33		40
11 (1/1999)	145	33		41 to 44
10 (1/1998)	145	41	Index	
4 (5/1995)	145	41	1	
4 (5/1995)	145	41	7 a10	
7 (12/1996)	145	41	11	
10 (1/1998)	145	41		12 to 15
7 (12/1996)	145	44	Index	
4 (5/1995)	145	44	2	
4 (5/1995)	145	44	7 to 10	
4 (5/1995)	145	44	12	
7 (12/1996)	145	44	13 to 14	
4 (5/1995)	145	44	15	
2 (9/1994)	145	44	17	
11 (1/1999)	145	44	18	
4 (5/1995)	145	44	20	
7 (12/1996)	145	44	22	
7 (12/1996)	145	44	24 to 26	

UPDATE CHART

146

146

VOLUME I
REPAIR
INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
2 (9/1994)	145-146	-	Frontespice	
2 (9/1994)	145-146	Introd.	1	
10 (1/1998)	145-146	00	Index	
10 (1/1998)	145	00	1 to 2	
6 (10/1996)	145	00	3	
10 (1/1998)	145	00	4 to 6	
10 (1/1998)	145	00	6/1 to 6/2	
2 (9/1994)	145	00	7 to 10	
4 (5/1995)	145	00	11	
2 (9/1994)	145	00	12 to 16	
4 (5/1995)	145	00	17	
7 (12/1996)	145	00	18 to 19	
2 (9/1994)	145	00	20 to 21	
7 (12/1996)	145	00	22	
9 (12/1997)	145	00	22/1	22/2 to 22/6
4 (5/1995)	145	00		
9 (12/1998)	145	00	22/7	
6 (10/1996)	145	00		22/8 to 22/12
10 (1/1998)	145	00		22/13 to 22/16
10 (1/1998)	145	00	23 to 30	
7 (12/1996)	145	00	30/1	
10 (1/1998)	145	00	30/2	
10 (1/1998)	145	00	31 to 32	
10 (1/1998)	145	00	32/1	
6 (10/1996)	145	00	32/2	
2 (9/1994)	145	00	33 to 35	
10 (1/1998)	145	00	36 to 57	
10 (1/1998)	145	00	57/1 to 57/2	
10 (1/1998)	145	00	57/3	
10 (1/1998)	145	00	57/4	57/5 to 57/8
10 (1/1998)	145	00	58	
2 (9/1994)	145	00	59	
6 (10/1996)	145	00		59/1 to 59/2
10 (1/1998)	145	00		59/3 to 59/6
2 (9/1994)	145	00	60 to 70	
10 (1/1998)	145	00	71	
2 (9/1994)	145	00	72 to 74	
7 (12/1996)	145	00		74/1 to 74/6
2 (9/1994)	145	00	75 to 79	
4 (5/1995)	145	00	80	
4 (5/1995)	145	00		80/1 to 80/2
6 (10/1996)	145	00	81 to 82	
4 (5/1995)	145	00	83 to 86	
6 (10/1996)	145	00		86/1 to 86/2

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
7 (12/1996)	145	00	87	
10 (1/1998)	145	00	88 to 90	
10 (1/1998)	146	00	91 to 97	
7 (12/1996)	146	00	98 to 99	
5 (9/1995)	145	10	Indice I-II	
7 (12/1996)	145	10	Index III-IV-V	
10 (1/1998)	145	10	Index VI	
10 (1/1998)	145	10		VII
2 (9/1994)	145	10		48/1 to 48/20
4 (5/1995)	145	10	56	
4 (5/1995)	145	10		56/1 to 56/2
4 (5/1995)	145	10	57	
10 (1/1998)	145	10	103	
4 (5/1995)	145	10	115 to 116	
7 (12/1996)	145	10	119	
4 (5/1995)	145	10	124	
4 (5/1995)	145	10	165 to 174	
5 (9/1995)	145	10		174/1 to 174/8
4 (5/1995)	145	10	175	
5 (9/1995)	145	10		175/1
4 (5/1995)	145	10	176 to 194	
7 (12/1996)	145	10	195	
4 (5/1995)	145	10	196	
7 (12/1996)	145	10		196/1 a 196/2
4 (5/1995)	145	10	197 to 202	
7 (12/1996)	145	10		202/1 a 202/6
4 (5/1995)	145	10	203 to 213	
7 (12/1996)	145	10	214 to 215	
4 (5/1995)	145	10	216 to 219	
7 (12/1996)	145	10	220 to 221	
4 (5/1995)	145	10	222	
7 (12/1996)	145	10	223 to 225	
7 (12/1996)	145	10		225/1 a 225/2
7 (12/1996)	145	10	226	
4 (5/1995)	145	10	227 to 234	
7 (12/1996)	145	10	235	
7 (12/1996)	145	10		236 to 260
9 (12/1997)	145	10		261
10 (1/1998)	145	10	262	
9 (12/1997)	145	10	263	
10 (1/1998)	145	10	264	
9 (12/1997)	145	10	265	
10 (1/1998)	145	10	266	

UPDATE CHART

146
146

VOLUME I
REPAIR
INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
9 (12/1997)	145	10	267	
10 (1/1998)	145	10	268 to 272	
10 (1/1998)	145	10		273 to 309
7 (12/1996)	145	18	Index	
4 (5/1995)	145	18		14 to 17
7 (12/1996)	145	18		18
7 (12/1996)	145	21	Index	
3 (1/1995)	145	21	6	
7 (12/1996)	145	21	14	
4 (5/1995)	145	21		15 to 20
7 (12/1996)	145	21	21	
7 (12/1996)	145			22 to 31
7 (12/1996)	145	27	Index	
2 (9/1994)	145	27	2	
4 (5/1995)	145	27	6	
4 (5/1995)	145	27		10 to 11
7 (12/1996)	145	27		12 to 16
7 (12/1996)	145	33	Index	
4 (5/1995)	145	33	4 to 7	
10 (1/1998)	145	33	7/1	
4 (5/1995)	145	33		7/2
7 (12/1996)	145	33	8 to 9	
7 (12/1996)	145	33		9/1 to 9/2
7 (12/1996)	145	33	10	
3 (1/1995)	145	33	15	
7 (12/1996)	145	33	17	
4 (5/1995)	145	33	26	
4 (5/1995)	145	33		27 to 28
7 (12/1996)	145	33		29 to 40
10 (1/1998)	145	41	Index	
4 (5/1995)	145	41	1	
4 (5/1995)	145	41	7 a10	
7 (12/1996)	145	41	11	
10 (1/1998)	145	41		12 to 15
7 (12/1996)	145	44	Index	
4 (5/1995)	145	44	2	
4 (5/1995)	145	44	7 a10	
4 (5/1995)	145	44	12	
7 (12/1996)	145	44	13 to 14	
4 (5/1995)	145	44	15	
2 (9/1994)	145	44	17 a18	
4 (5/1995)	145	44	20	
7 (12/1996)	145	44	22	
7 (12/1996)	145	44	24 to 26	