

145
146

VOLUME III
SECTION II
REPAIR
INSTRUCTIONS

ELECTRIC SYSTEM DIAGNOSIS

Section 34 to 40, Appendix and specific 146 sections

55

Alfa Romeo 

UPDATE CHART

146

146

VOLUME III
REPAIR
INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
8 (6/1997)	145	55-36B	11 to 12	
6 (10/1996)	145	55-36B		13 to 16
8 (6/1997)	145	55-36B	17	
6 (10/1996)	145	55-36B		18 to 24
9 (12/1997)	145	55-36C		1
13 (6/1999)	145	55-36C	2	
12 (2/1999)	145	55-36C	3 to 4	
13 (6/1999)	145	55-36C	5 to 6	
12 (2/1999)	145	55-36C	7 to 9	
13 (6/1999)	145	55-36C	10	
9 (12/1997)	145	55-36C		11
13 (6/1999)	145	55-36C	12	
12 (2/1999)	145	55-36C	13 to 14	
13 (6/1999)	145	55-36C	15 to 17	
12 (2/1999)	145	55-36C	18	
6 (10/1996)	145	55-37	1	
4 (5/1995)	145	55-37	2 to 4	
4 (5/1995)	145	55-37		4/1 to 4/2
2 (9/1994)	145	55-37	5	
4 (5/1995)	145	55-37	6 to 19	
6 (10/1996)	145	55-37A	1 to 3	
4 (5/1995)	145	55-37A		4 to 5
6 (10/1996)	145	55-37A	6 to 9	
6 (10/1996)	145	55-37A		9/1
8 (6/1997)	145	55-37A	9/2	
7 (12/1996)	145	55-37A	10	
4 (5/1995)	145	55-37A		11
8 (6/1997)	145	55-37A	12	
6 (10/1996)	145	55-37A	13	
8 (6/1997)	145	55-37A	14	
6 (10/1996)	145	55-37A		14/1 to 14/4
8 (6/1997)	145	55-37A	15	
6 (10/1996)	145	55-37A	16	
7 (12/1996)	145	55-37A		17 to 18
4 (5/1995)	145	55-37A	19	
5 (9/1995)	145	55-37A		20 to 21
4 (5/1995)	145	55-37A		1 to 2
10 (1/1998)	145	55-37B		1 to 2
12 (2/1999)	145	55-37B	3	
10 (1/1998)	145	55-37B		4
12 (2/1999)	145	55-37B	5 to 15	
10 (1/1998)	145	55-37B		16
12 (2/1999)	145	55-37B	17 to 18	
10 (1/1998)	145	55-38	1	
6 (10/1996)	145	55-38	2	
2 (9/1994)	145	55-38	7	

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
6 (10/1996)	145	55-38	8	
8 (6/1997)	145	55-38		8/1 to 8/2
8 (6/1997)	145	55-38	9 to 10	
6 (10/1996)	145	55-38	11	
8 (6/1997)	145	55-38	12	
6 (10/1996)	145	55-38	12/1 to 12/2	
9 (12/1997)	145	55-38	12/3 to 12/8	
9 (12/1997)	145	55-38		12/9 to 12/10
10 (1/1998)	145	55-38		12/11 to 12/16
10 (1/1998)	145	55-38	13	
6 (10/1996)	145	55-38	14	
2 (9/1994)	145	55-39	2	
2 (9/1994)	145	55-39	6	
2 (9/1994)	145	55-39	9	
2 (9/1994)	145	55-39	17	
9 (12/1997)	145	55-39A	1	
6 (10/1996)	145	55-39A		2
8 (6/1997)	145	55-39A		2/1 to 2/2
8 (6/1997)	145	55-39A	3 to 6	
6 (10/1996)	145	55-39A		7 to 13
9 (12/1997)	145	55-39B		1
12 (2/1999)	145	55-39B	2 to 6	
9 (12/1997)	145	55-39B		6 to 8
12 (2/1999)	145	55-39B	9	
10 (1/1998)	145	55-40	1	
12 (2/1999)	145	55-40	2	
1 (9/1994)	145	55-40		3 to 6
12 (2/1999)	145	55-40	7	
1 (9/1994)	145	55-40		8 to 10
12 (2/1999)	145	55-40	11 to 13	
1 (9/1994)	145	55-40		14
6 (10/1996)	145	55-40	15 to 16	
6 (10/1996)	145	55-40		16/1
9 (12/1997)	145	55-40	16/2	
12 (2/1999)	145	55-40	16/3 to 16/4	
6 (10/1996)	145	55-40	17 to 18	
8 (6/1997)	145	55-40		18/1
12 (2/1999)	145	55-40	18/2	
12 (2/1999)	145	55-40	19	
10 (1/1998)	145	55-40	20	
9 (12/1997)	145	55-40	21	
12 (2/1999)	145	55-40	22 to 23	
10 (1/1998)	145	55-40	24	
12 (2/1999)	145	55-40	24/1	
9 (12/1997)	145	55-40	24/2	
12 (2/1999)	145	55-40	25	

(continues)

6-1999

UPDATE CHART

146

146

VOLUME III

REPAIR

INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
10 (1/1998)	145	55-40	26	
12 (2/1999)	145	55-40	26/1	
10 (1/1998)	145	55-40		26/2
1 (1/1994)	145	55-40		27 to 28
3 (1/1995)	145	55-40	29	
12 (2/1999)	145	55-41	1 to 6	
			to be eliminated	
12 (2/1999)	145	55-A1	2 to 4	
12 (2/1999)	146	55	Index	
10 (1/1998)	146	55-1	1	
5 (9/1995)	146	55-1	2	
3 (1/1995)	146	55-1	3 to 6	
2 (9/1994)	146	55-1		7
3 (1/1995)	146	55-1	8	
4 (5/1995)	146	55-1	9 to 11	
6 (10/1996)	146	55-1	12	
10 (1/1998)	146	55-1	12/1	
8 (6/1997)	146	55-1	12/2	
6 (10/1996)	146	55-1	13 to 17	
12 (2/1999)	146	55-1	18/1 to 18/2	
12 (2/1999)	146	55-1	19	
9 (12/1997)	146	55-1	20 to 21	
12 (2/1999)	146	55-1	21/1	
10 (1/1998)	146	55-1		21/2
12 (2/1999)	146	55-1	21/3 to 21/4	
10 (1/1998)	146	55-1		21/5 to 21/6
10 (1/1998)	146	55-1	22	
2 (9/1994)	146	55-2		1 to 2
12 (2/1999)	146	55-2	3 to 4	
2 (9/1994)	146	55-2		5
9 (12/1997)	146	55-2	6	
12 (2/1999)	146	55-2	6/1 to 6/2	
9 (12/1997)	146	55-2		6/3 to 6/4
6 (10/1996)	146	55-2	7	
2 (9/1994)	146	55-2		8
12 (2/1999)	146	55-2	9	
9 (12/1997)	146	55-2	10	
10 (1/1998)	146	55-2	11	
12 (2/1999)	146	55-2	12 to 15	
10 (1/1998)	146	55-2	16	
12 (2/1999)	146	55-2	16/1	
9 (12/1997)	146	55-2		16/2
10 (1/1997)	146	55-2	17	
12 (2/1999)	146	55-2	19 to 20	
8 (6/1997)	146	55-3	1	
2 (9/1994)	146	55-3		2 to 3

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
8 (6/1997)	146	55-3	4	
8 (6/1997)	146	55-3		4/1 to 4/2
6 (10/1996)	146	55-3	5 to 6	
2 (9/1994)	146	55-3		7
6 (10/1996)	146	55-3	8	
2 (9/1994)	146	55-3		9
6 (10/1996)	146	55-3	10 to 13	
2 (9/1994)	146	55-3		14
6 (10/1996)	146	55-3	15	
10 (1/1998)	146	55-3	16 to 17	
8 (6/1997)	146	55-3	18	
10 (1/1998)	146	55-3	19	
9 (12/1997)	146	55-3	20 to 21	
8 (6/1997)	146	55-3		22 to 23
12 (2/1999)	146	55-3	24	
8 (6/1997)	146	55-3		25 to 26
10 (1/1998)	146	55-3	27	
8 (6/1997)	146	55-3		28
10 (1/1998)	146	55-3	29	
2 (9/1994)	146	55-5		1 to 2
8 (6/1997)	146	55-5		2/1 to 2/2
8 (6/1997)	146	55-5	3	
2 (9/1994)	146	55-5		4
8 (6/1997)	146	55-5	5 to 7	
2 (9/1994)	146	55-5		8
8 (6/1997)	146	55-8	1	
2 (9/1994)	146	55-8		2 to 3
6 (10/1996)	146	55-8	4	
6 (10/1996)	146	55-8		4/1
8 (6/1997)	146	55-8	4/2	
8 (6/1997)	146	55-8		4/3 to 4/4
8 (6/1997)	146	55-8	5 to 10	
8 (6/1997)	146	55-8		10/1 to 10/2
6 (10/1996)	146	55-8	11	
6 (10/1996)	146	55-8		12
12 (2/1999)	146	55-11	1	
2 (9/1994)	146	55-11		2
6 (10/1996)	146	55-11	3	
8 (6/1997)	146	55-11	4	
8 (6/1997)	146	55-11		4/1 to 4/2
8 (6/1997)	146	55-11	5	
2 (9/1994)	146	55-11		6
8 (6/1997)	146	55-11	7 to 9	
2 (9/1994)	146	55-11		10
12 (2/1999)	146	55-11	11	
12 (2/1999)	146	55-11A		1 to 9

UPDATE CHART

146

146

VOLUME III
REPAIR
INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
8 (6/1997)	146	55-12	1	
2 (9/1994)	146	55-12		2/1 to 2/2
8 (6/1997)	146	55-12	3 to 8	
8 (6/1997)	146	55-12		8/1 to 8/2
2 (9/1994)	146	55-12		9 to 10
2 (9/1994)	146	55-13		1
8 (6/1997)	146	55-13		2/1 to 2/2
8 (6/1997)	146	55-13	3 to 5	
8 (6/1997)	146	55-14	1	
6 (10/1996)	146	55-14	2	
10 (1/1998)	146	55-14	2/1	
8 (6/1997)	146	55-14		2/2
8 (6/1997)	146	55-14	3	
10 (1/1998)	146	55-14	4	
9 (12/1997)	146	55-14	5	
10 (1/1998)	146	55-14	6 to 7	
8 (6/1997)	146	55-16	1	
2 (9/1994)	146	55-16		2 to 3
6 (10/1996)	146	55-16	4	
8 (6/1997)	146	55-16	4/1 to 4/2	
8 (6/1997)	146	55-16	5 to 9	
2 (9/1994)	146	55-16	6	
6 (10/1996)	146	55-16	7 to 9	
2 (9/1994)	146	55-16	10	
7 (12/1996)	146	55-16	11	
2 (9/1994)	146	55-16		12 to 14
8 (6/1997)	146	55-18	1	
2 (9/1994)	146	55-18		2 to 3
8 (6/1997)	146	55-18	4	
8 (6/1997)	146	55-18		4/1 to 4/2
2 (9/1994)	146	55-18		5 to 8
6 (10/1996)	146	55-18	9	
8 (6/1997)	146	55-18	10	
8 (6/1997)	146	55-18		10/1 to 10/2
8 (6/1997)	146	55-18	11 to 12	
2 (9/1994)	146	55-18		13
2 (9/1994)	146	55-19		1 to 2
8 (6/1997)	146	55-19		2/1 to 2/2
8 (6/1997)	146	55-19	3 to 4	
2 (9/1994)	146	55-19		5
8 (6/1997)	146	55-19	6	
2 (9/1994)	146	55-19		7
8 (6/1997)	146	55-19	8	
2 (9/1994)	146	55-19		9 to 11
8 (6/1997)	146	55-21	1	
2 (9/1994)	146	55-21		a 2

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
6 (10/1996)	146	55-21	3	
8 (6/1997)	146	55-21	4	
8 (6/1997)	146	55-21		4/1 to 4/2
8 (6/1997)	146	55-21	5 to 10	
8 (6/1997)	146	55-21		10/1 to 10/2
2 (9/1994)	146	55-21		11 to 13
2 (9/1994)	146	55-22		1
5 (9/1995)	146	55-22	2	
8 (6/1997)	146	55-22		2/1 to 2/2
8 (6/1997)	146	55-22	3 to 6	
2 (9/1994)	146	55-22		7
8 (6/1997)	146	55-23	1	
6 (10/1996)	146	55-23	2 to 3	
8 (6/1997)	146	55-23	4	
8 (6/1997)	146	55-23		4/1 to 4/2
8 (6/1997)	146	55-23	5 to 6	
6 (10/1996)	146	55-23	7	
8 (6/1997)	146	55-23	8 to 9	
2 (9/1994)	146	55-23		10
9 (12/1997)	146	55-23	10/1	
8 (6/1997)	146	55-23		10/2
8 (6/1997)	146	55-23	11 to 14	
8 (6/1997)	146	55-23		14/1 to 14/2
2 (9/1994)	146	55-23		15 to 17
8 (6/1997)	146	55-24	1	
3 (1/1995)	146	55-24	2	
6 (10/1996)	146	55-24		2/1
10 (1/1998)	146	55-24	2/2	
8 (6/1997)	146	55-24	3	
10 (1/1998)	146	55-24	4	
8 (6/1997)	146	55-24	5 to 6	
8 (6/1997)	146	55-24		6/1 to 6/2
3 (1/1995)	146	55-24		7
6 (10/1996)	146	55-24		8
6 (10/1996)	146	55-26	1	
2 (9/1994)	146	55-26		2 to 26
2 (9/1994)	146	55-A1		1
12 (2/1999)	146	55-A1	2 to 5	

UPDATE CHART

146 146

VOLUME III
REPAIR
INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
4 (5/1995)	145	55-37A		4 to 5
6 (10/1996)	145	55-37A	6 to 9	
6 (10/1996)	145	55-37A		9/1
8 (6/1997)	145	55-37A	9/2	
7 (12/1996)	145	55-37A	10	
4 (5/1995)	145	55-37A		11
8 (6/1997)	145	55-37A	12	
6 (10/1996)	145	55-37A	13	
8 (6/1997)	145	55-37A	14	
6 (10/1996)	145	55-37A		14/1 to 14/4
8 (6/1997)	145	55-37A	15	
6 (10/1996)	145	55-37A	16	
7 (12/1996)	145	55-37A		17 to 18
4 (5/1995)	145	55-37A	19	
4 (5/1995)	145	55-37A		20 to 21
10 (1/1998)	145	55-37B		1 to 2
12 (2/1999)	145	55-37B	3	
10 (1/1998)	145	55-37B		4
12 (2/1999)	145	55-37B	5 to 15	
10 (1/1998)	145	55-37B		16
12 (2/1999)	145	55-37B	17 to 18	
10 (1/1998)	145	55-38	1	
6 (10/1996)	145	55-38	2	
2 (9/1994)	145	55-38	7	
6 (10/1996)	145	55-38	8	
8 (6/1997)	145	55-38		8/1 to 8/2
8 (6/1997)	145	55-38	9 to 10	
6 (10/1996)	145	55-38	11	
8 (6/1997)	145	55-38	12	
6 (10/1996)	145	55-38	12/1 to 12/2	
9 (12/1997)	145	55-38	12/3 to 12/8	
9 (12/1997)	145	55-38		12/9 to 12/10
10 (1/1998)	145	55-38		12/11 to 12/16
10 (1/1998)	145	55-38	13	
6 (10/1996)	145	55-38	14	
2 (9/1994)	145	55-39	2	
2 (9/1994)	145	55-39	6	
2 (9/1994)	145	55-39	9	
2 (9/1994)	145	55-39	17	
9 (12/1997)	145	55-39A	1	
6 (10/1996)	145	55-39A		2
8 (6/1997)	145	55-39A		2/1 to 2/2
8 (6/1997)	145	55-39A	3 to 6	
6 (10/1996)	145	55-39A		7 to 13
9 (12/1997)	145	55-39B		1

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
12 (2/1999)	145	55-39B	2 to 6	
9 (12/1997)	145	55-39B		6 to 8
12 (2/1999)	145	55-39B	9	
10 (1/1998)	145	55-40	1	
12 (2/1999)	145	55-40	2	
1 (9/1994)	145	55-40		3 to 6
12 (2/1999)	145	55-40	7	
1 (9/1994)	145	55-40		8 to 10
12 (2/1999)	145	55-40	11 to 13	
1 (9/1994)	145	55-40		14
6 (10/1996)	145	55-40	15 to 16	
6 (10/1996)	145	55-40		16/1
9 (12/1997)	145	55-40	16/2	
12 (2/1999)	145	55-40	16/3 to 16/4	
6 (10/1996)	145	55-40	17 to 18	
8 (6/1997)	145	55-40		18/1
12 (2/1999)	145	55-40	18/2	
12 (2/1999)	145	55-40	19	
10 (1/1998)	145	55-40	20	
9 (12/1997)	145	55-40	21	
12 (2/1999)	145	55-40	22 to 23	
10 (1/1998)	145	55-40	24	
12 (2/1999)	145	55-40	24/1	
9 (12/1997)	145	55-40	24/2	
12 (2/1999)	145	55-40	25	
10 (1/1998)	145	55-40	26	
12 (2/1999)	145	55-40	26/1	
10 (1/1998)	145	55-40		26/2
1 (1/1994)	145	55-40		27 to 28
3 (1/1995)	145	55-40	29	
12 (2/1999)	145	55-41	1 to 6	
			to be eliminated	
12 (2/1999)	145	55-A1	2 to 4	
12 (2/1999)	146	55		
10 (1/1998)	146	55-1	1	
5 (9/1995)	146	55-1	2	
3 (1/1995)	146	55-1	3 to 6	
2 (9/1994)	146	55-1		7
3 (1/1995)	146	55-1	8	
4 (5/1995)	146	55-1	9 to 11	
6 (10/1996)	146	55-1	12	
10 (1/1998)	146	55-1	12/1	
8 (6/1997)	146	55-1	12/2	
6 (10/1996)	146	55-1	13 to 17	
12 (2/1999)	146	55-1	18/1 to 18/2	
12 (2/1999)	146	55-1	19	

UPDATE CHART

146

146

VOLUME III REPAIR INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
9 (12/1997)	146	55-1	20 to 21	
12 (2/1999)	146	55-1	21/1	
10 (1/1998)	146	55-1		21/2
12 (2/1999)	146	55-1	21/3 to 21/4	
10 (1/1998)	146	55-1		21/5 to 21/6
10 (1/1998)	146	55-1	22	
2 (9/1994)	146	55-2		1 to 2
12 (2/1999)	146	55-2	3 to 4	
2 (9/1994)	146	55-2		5
9 (12/1997)	146	55-2	6	
12 (2/1999)	146	55-2	6/1 to 6/2	
9 (12/1997)	146	55-2		6/3 to 6/4
6 (10/1996)	146	55-2	7	
2 (9/1994)	146	55-2		8
12 (2/1999)	146	55-2	9	
9 (12/1997)	146	55-2	10	
10 (1/1998)	146	55-2	11	
12 (2/1999)	146	55-2	12 to 15	
10 (1/1998)	146	55-2	16	
12 (2/1999)	146	55-2	16/1	
9 (12/1997)	146	55-2		16/2
10 (1/1997)	146	55-2	17	
12 (2/1999)	146	55-2	19 to 20	
8 (6/1997)	146	55-3	1	
2 (9/1994)	146	55-3		2 to 3
8 (6/1997)	146	55-3	4	
8 (6/1997)	146	55-3		4/1 to 4/2
6 (10/1996)	146	55-3	5 to 6	
2 (9/1994)	146	55-3		7
6 (10/1996)	146	55-3	8	
2 (9/1994)	146	55-3		9
6 (10/1996)	146	55-3	10 to 13	
2 (9/1994)	146	55-3		14
6 (10/1996)	146	55-3	15	
10 (1/1998)	146	55-3	16 to 17	
8 (6/1997)	146	55-3	18	
10 (1/1998)	146	55-3	19	
9 (12/1997)	146	55-3	20 to 21	
8 (6/1997)	146	55-3		22 to 23
12 (2/1999)	146	55-3	24	
8 (6/1997)	146	55-3		25 to 26
10 (1/1998)	146	55-3	27	
8 (6/1997)	146	55-3		28
10 (1/1998)	146	55-3	29	
2 (9/1994)	146	55-5		1 to 2
8 (6/1997)	146	55-5		2/1 to 2/2

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
8 (6/1997)	146	55-5	3	
2 (9/1994)	146	55-5		4
8 (6/1997)	146	55-5	5 to 7	
2 (9/1994)	146	55-5		8
8 (6/1997)	146	55-8	1	
2 (9/1994)	146	55-8		2 to 3
6 (10/1996)	146	55-8	4	
6 (10/1996)	146	55-8		4/1
8 (6/1997)	146	55-8	4/2	
8 (6/1997)	146	55-8		4/3 to 4/4
8 (6/1997)	146	55-8	5 to 10	
8 (6/1997)	146	55-8		10/1 to 10/2
6 (10/1996)	146	55-8	11	
6 (10/1996)	146	55-8		12
12 (2/1999)	146	55-11	1	
2 (9/1994)	146	55-11		2
6 (10/1996)	146	55-11	3	
8 (6/1997)	146	55-11	4	
8 (6/1997)	146	55-11		4/1 to 4/2
8 (6/1997)	146	55-11	5	
2 (9/1994)	146	55-11		6
8 (6/1997)	146	55-11	7 to 9	
2 (9/1994)	146	55-11		10
12 (2/1999)	146	55-11	11	
12 (2/1999)	146	55-11A		1 to 9
8 (6/1997)	146	55-12	1	
2 (9/1994)	146	55-12		2/1 to 2/2
8 (6/1997)	146	55-12	3 to 8	
8 (6/1997)	146	55-12		8/1 to 8/2
2 (9/1994)	146	55-12		9 to 10
2 (9/1994)	146	55-13		1
8 (6/1997)	146	55-13		2/1 to 2/2
8 (6/1997)	146	55-13	3 to 5	
8 (6/1997)	146	55-14	1	
6 (10/1996)	146	55-14	2	
10 (1/1998)	146	55-14	2/1	
8 (6/1997)	146	55-14		2/2
8 (6/1997)	146	55-14	3	
10 (1/1998)	146	55-14	4	
9 (12/1997)	146	55-14	5	
10 (1/1998)	146	55-14	6 to 7	
8 (6/1997)	146	55-16	1	
2 (9/1994)	146	55-16		2 to 3
6 (10/1996)	146	55-16	4	
8 (6/1997)	146	55-16	4/1 to 4/2	
8 (6/1997)	146	55-16	5 to 9	

UPDATE CHART

146

146

VOLUME III

REPAIR

INSTRUCTIONS

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
2 (9/1994)	146	55-16	6	
6 (10/1996)	146	55-16	7 to 9	
2 (9/1994)	146	55-16	10	
7 (12/1996)	146	55-16	11	
2 (9/1994)	146	55-16		12 to 14
8 (6/1997)	146	55-18	1	
2 (9/1994)	146	55-18		2 to 3
8 (6/1997)	146	55-18	4	
8 (6/1997)	146	55-18		4/1 to 4/2
2 (9/1994)	146	55-18		5 to 8
6 (10/1996)	146	55-18	9	
8 (6/1997)	146	55-18	10	
8 (6/1997)	146	55-18		10/1 to 10/2
8 (6/1997)	146	55-18	11 to 12	
2 (9/1994)	146	55-18		13
2 (9/1994)	146	55-19		1 to 2
8 (6/1997)	146	55-19		2/1 to 2/2
8 (6/1997)	146	55-19	3 to 4	
2 (9/1994)	146	55-19		5
8 (6/1997)	146	55-19	6	
2 (9/1994)	146	55-19		7
8 (6/1997)	146	55-19	8	
2 (9/1994)	146	55-19		9 to 11
8 (6/1997)	146	55-21	1	
2 (9/1994)	146	55-21		a 2
6 (10/1996)	146	55-21	3	
8 (6/1997)	146	55-21	4	
8 (6/1997)	146	55-21		4/1 to 4/2
8 (6/1997)	146	55-21	5 to 10	
8 (6/1997)	146	55-21		10/1 to 10/2
2 (9/1994)	146	55-21		11 to 13
2 (9/1994)	146	55-22		1
5 (9/1995)	146	55-22	2	
8 (6/1997)	146	55-22		2/1 to 2/2
8 (6/1997)	146	55-22	3 to 6	
2 (9/1994)	146	55-22		7
8 (6/1997)	146	55-23	1	
6 (10/1996)	146	55-23	2 to 3	
8 (6/1997)	146	55-23	4	
8 (6/1997)	146	55-23		4/1 to 4/2
8 (6/1997)	146	55-23	5 to 6	
6 (10/1996)	146	55-23	7	
8 (6/1997)	146	55-23	8 to 9	
2 (9/1994)	146	55-23		10
9 (12/1997)	146	55-23	10/1	
8 (6/1997)	146	55-23		10/2

UPDATE CHART				
UPDATE (DATE)	MODEL	SECTION	PAGE	
			SOBST.	ADDED
8 (6/1997)	146	55-23	11 to 14	
8 (6/1997)	146	55-23		14/1 to 14/2
2 (9/1994)	146	55-23		15 to 17
8 (6/1997)	146	55-24	1	
3 (1/1995)	146	55-24	2	
6 (10/1996)	146	55-24		2/1
10 (1/1998)	146	55-24	2/2	
8 (6/1997)	146	55-24	3	
10 (1/1998)	146	55-24	4	
8 (6/1997)	146	55-24	5 to 6	
8 (6/1997)	146	55-24		6/1 to 6/2
3 (1/1995)	146	55-24		7
6 (10/1996)	146	55-24		8
6 (10/1996)	146	55-26	1	
2 (9/1994)	146	55-26		2 to 26
2 (9/1994)	146	55-A1		1
12 (2/1999)	146	55-A1	2 to 5	

