

159 Pollen filter replacement

Tools needed: 5.5mm hex socket and ratchet, TX25 bit and ratchet, small hands.

1. Open Glove box, remove rh cover piece (give it a yank and it will unclip). Using TX25 bit unscrew the torx bolt on the filter cover flap. Release the 2 clips on the upper edge and the cover drops down. Pull it towards you to remove.



2. Remove the glove box light switch from its clevis and push it and the wires down out of the way.



3. Unscrew hex bolt using 5.5mm socket and remove. Lift the flap and remove the filter.



4. fit new filter, note direction arrow of filter. I also write date of fitting on the side visible in the flap as per pic above. Close and bolt down flap, refit light switch, and replace covers. Bask in clean free flowing air!.